PHILIPS

TV

15 AB 3536
17 AB 3546
21 AB 3556

PHILIPS

PHILIPS

Downloaded from www.Manualslib.com manuals search engine

Downloaded from www.Manualslib.com manuals search engine

English

Contents

Unpack and Connect pg.2
Mains and aerial
Remote control
Switching TV on
Stand-by
Indoor aerial

GB

Installation pg.3
Activeting the instell menu
Selecting your menu language
Searching and storing TV channels

Manual store pg.4
Selecting the TV system
Searching for a TV channel
Allocating the programme number to a TV channel pg.5
Adjusting the volume
Storing

Auto store pg.6

Favourite Programmes pg.7

Operation pg.8
Selecting TV channels
Volume control
Temporarily interrupting the sound
Time, date, stop-watch
Sleep timer
Personal Preference
Brightness and Colour control

Main menu pg.9
Adjusting the picture
Special feetures pg.10
Clock, setting time and dete pg.11
Alarm

Teletext pg.12

Peripheral connections pg.14
Connecting via aerial cable pg.15
Connecting via eurocable
Connecting vie audio/video cables
Headphones

Tips pg.16
Demo

Follow these instructions carefully.
○ This circle in front of a sentence indicates that you have to do something.
▷ This arrow in front of a sentence indicates the result of what you have done.

Downloaded from www.Manualslib.com manuals search engine

Unpack and Connect

1 Positioning

Place the TV on a solid surface.
For ventilation, leave a space of at least 5 cm. free all around the set.

2 Mains and aerial

This TV requires a mains voltage of 220/240 Volts, 50 Hz. Consult your dealer if the mains supply is different.

- O Insert the mains plug into the wall socket.
- O Insert the aerial connector into the aerial socket ⌐⌐ on the back of the TV and into the wall aerial socket.

3 Remote control

Your remote control has two sides with buttons. For the best result use the remote control in the horizontal position. When you turn the remote control you will hear the switch. This switch makes sure that the upper part can be activated. The bottom part is desactivated. Pressing buttons in this part will not have any effect.

- O Remove the battery compartment cover.
- O Insert the batteries supplied (1,5 Volts).
- O Close the battery cover.



4 Switching TV on

- O Press the switch ⏻ on the front of your TV set.



Does a red light on the TV light up? Then the TV is on Stand-by.

- O Press P — or + on the remote control.
- ▷ The TV switches on.

Stand-by

- O By pressing ⏻ (Red) on the remote control you can temporerily switch the TV off.
- ▷ A red light on the TV lights up.
- O Press P — or + to switch on the TV again.

Switch off your TV overnight instead of leaving it on Stand-by. You save energy and the picture tube is demagnetised which helps to maintain a good picture quality.

Automatic Stand-by

If after a period of 15 minutes no aerial signal is received, the TV automatically switches to Stand-by.

Indoor aerial

Read the following information only if you are using an indoor aerial.

On certain TV models the aerial is included in the box.
Insert the aerial into the mounting socket located on the back of the TV, then insert the aerial connector into the aerial socket ⌐⌐.

In some circumstances (specific regions or if surrounded by high buildings) reception problems could occur.
Further improvement of reception could be obtained by:

- Rotating or varying the angle of the aerial.
- Using other aerial executions.
- Connecting your TV to en outdoor aerial.

Control panel

The control buttons needed for adjusting the TV are located behind the control panel cover on the front of the TV.
To open, simply press on the middle of the panel cover.

Downloaded from www.Manualslib.com manuals search engine

Installation

This part helps you with finding TV channels, allocating tha TV channels on the programme numbers and adjusting picture and sound.

GB

1 Activating the INSTALLATION menu

○ Press the two **INSTALL** buttons on the remote control at the same time, or press the **INSTALL** button on the front of the TV.
▷ **INSTALLATION** menu appears on the screen.

INSTALLATION
A LANGUAGE
B MANUAL STORE
C AUTO STORE
D SORT
E FAVOURITE PROG.

Select the menu item using the colour buttons A **B C D E** on the remote control.



2 Selecting your menu language

You can choose tha language of the menus which are shown on the screen.

○ Select **LANGUAGE.**
▷ A menu of languages appears.

LANGUAGE
A ENGLISH
B DEUTSCH
C FRANCAIS
D ITALIANO
E ...

○ Select E ... if your language does not appaar on the first language menu.
▷ A second menu of languages appears.

○ Select the colour button for your language choice.
▷ **INSTALLATION** menu appears again.

From this point on, all menus are presented in the language of your choice.

HELP **You can always press the MENU button on your remote control to go back to the INSTALLATION menu, or press OFF to leave tha menu.**

3 Searching and storing TV channels

After you have selected your menu language, you can saarch for and store your TV channels using **MANUAL STORE** or **AUTO STORE.**
If you want to store all the TV channels automatically, use AUTO **STORE** (see page 6).
After **AUTO STORE** you only have to allocate the TV channels on the programma numbers.
If you want to store the TV channels step-by-step, use MANUAL **STORE** (see page 4).

Downloaded from www.Manualslib.com manuals search engine

MANUAL STORE

1

The **INSTALL** menu must be on the screen. If not press the two **INSTALL** buttons on the remota control at the same time, or press the **INSTALL** button on the front of the TV.

HELP

You can always press the MENU button on your remote control to go back to the INSTALLATION menu, or press OFF to laave the menu.

2

○ Select the **MANUAL STORE** menu.
▷ The following menu appears.

MANUAL STORE
A SYSTEM
B SEARCH
C PROGRAM NUMBER
D VOLUME
E STORE



3

Selecting the TV system

The television picture is not broedcasted in the same way in all countries.
You can change the TV system per programme numbar. Tharefore you must select the appropriate TV system.

○ Select **SYSTEM** from the manu.
▷ The first available country or region appears below the menu.
Select your ragion or country:

Region	TV Systam	Used in:
WEST EUROPE	PAL BG - SECAM BG	West European countries except France, except United Kingdom and Ireland.
FRANCE	SECAM L L'	France.
UK	PAL I	United Kingdom and Ireland.

○ Press — or + button to select the required country or region.

4

Searching for a TV channel

○ Select **SEARCH** from the menu.
▷ The TV searches for the first TV channel that can be received.
One or more blocks appear below the menu. The blocks change the colour when a TV channel is found. As soon as a TV channel has been found, you can see the programme on the screen.

Do you want to search for a particular TV channel? Then select **SEARCH** again.

Downloaded from www.Manualslib.com manuals search engine

GB

1 Allocating the programme number to a TV channel

○ Select **PROGRAMME NUMBER** from the menu.
▷ A programme number appears below the menu.
○ Press — or + or press one or two digit buttons to select the programme number on which you want to store the TV channel.

2 Adjusting the volume

The volume broedcested may differ for each channel. Here you can set your personal sound level per channel. When you press the green PP (Personal Preference) button on the remote control, the sound will automatically jump to your preferred level for this channel.

○ Press **PP**.
○ Select **VOLUME** from the menu.
▷ The volume indicators appears below the menu.
○ Press — or + button to adjust the volume.

Note : This "volume per channel" is related to the setting of the green PP (Personal Preference) button. The "volume per channel" will change, when you adapt the Personal Preference. (See page 10).

7 Storing

○ Select **STORE** from the menu.
▷ **STORED** appears below the menu. All the previous steps are stored in the memory.

REPEAT For every TV channel you want to store, repeet steps **3** to **7**. In some countries you can receive several broadcasting systems. If you want to store a TV chennel in another system then, in step **3**, change the TV system.

HELP **You can always press the MENU button on your remote control to go back to the INSTALLATION menu, or press OFF to leave the menu.**

Downloaded from www.Manualslib.com manuals search engine

AUTO STORE

1 The TV itself searches automatically for the TV channel. **Do not use AUTOSTORE if you have already stored the TV channels with MANUAL STORE.**
The **INSTALL** menu must be on the screen. If not press the two **INSTALL** buttons on the remote control at the same time, or press the **INSTALL** button on the front of the TV.

2 ○ Select **AUTO STORE** from the menu.



3 ○ Press — or + to activate the automatic store.
▷ Blue blocks appear. The TV searches for all TV channels and stores them automatically in the memory starting from block 59.
Blocks become yellow when a TV channel is stored. It will take some minutes to store all the TV channels.
Note: The TV searches for TV channels in all systems. Your TV stores a channel if a signal is received, even if it is a channel with no sound or no picture. After the TV channels heve been stored, the **INSTALLATION** menu reappears.

4 ○ Now select **SORT** from the **INSTALLATION** menu to allocate the TV channels to the preferred programme numbers.
▷ Blue and yellow blocks appear.
Yellow blocks indicate stored TV channels.

5 ○ Select **FROM.**
▷ The programme number of the TV channel you are currently looking at appears on the screen.
○ Press — or + or the digit buttons if you want to select a different TV channel.
▷ The block indicating the selected number is red.



6 ○ Select **TO.**
▷ A programme number appears on the screen.
○ Press — or + or the digit buttons to select the block to which you want to move the TV channel.
▷ The selected block is green.

7 ○ Select **STORE.**
▷ The TV channel is now stored on the new programme number. The block indicating this progremme is now yellow.

REPEAT Go back to 5 and repeat the sequence for each channel you want to move.

HELP **You can always press the MENU button on your remote control to go back to the INSTALLATION menu, or press OFF to leave the menu.**

Downloaded from www.Manualslib.com manuals search engine

GB

FAVOURITE PROGRAMMES

With the **MANUAL STORE** or **AUTO STORE** all the TV channels are now allocated on the programme numbers. With the — **P** + button you can go through all TV channels. You may prefer some programmes more than others. With **FAVOURITE PROGRAMMES** it is possible to jump from one favourite programme to another using the — **P** + button. You just jump over your NOT favourite programmes. These progremmes are still accessible using the digits on your remote control. Follow these steps to indicate your **favourite programmes.**

1 The **INSTALL** menu must be on the screen. If not press the two **INSTALL** buttons on the remote control at the same time, or press the **INSTALL** button on the front of the TV.

2 ○ Select **FAVOURITE PROG.** from the **INSTALLATION** menu.
▷ Blue and yellow blocks appear on the screen, blue blocks are non favourite programmes, yellow blocks are fevourite programmes.



3 ○ Select **PROG.NO.**
▷ The block representing the programme number you ere looking at is red.
○ Select a programme number using the — or + or the **digit** buttons.

4 ○ Select **FAVOURITE.**
▷ **ON / OFF** appears below the menu.
ON means favourite programme. OFF means not favourite programme. In this case you will jump over this programme when you are using the — **P** +.
Note that the not favourite programme numbers can still be selected with the digit buttons on your remote control.

5 ○ Press — or + to select **ON/OFF.**

6 ○ Select **STORE.**
▷ The selection is stored.
Repeat steps **3** to **6** for each programme number you want to make favourite or non favourite.

HELP **You can always press the MENU button on your remote control to go back to the INSTALLATION menu, or press OFF to leave the menu.**

Downloaded from www.Manualslib.com manuals search engine

Operation

Selecting a TV channel



○ Press P — or + or press one or two digit buttons on the remote control, or
Press P — or + on the TV.
▷ The programme number of the selected TV channel appears on the screen.

○ If you press P◂P on the remote control the TV switches to the previous selected TV programme.

Volume control



○ Press ◿ — or + on the remote control, or Press ◿ — or + on the TV.

Temporarily silencing the sound

○ Press 🔇 (mute) on the remote control.
▷ The sound is temporarily silenced and the symbol 🔇 appears.
Do you want the sound back?
○ Press 🔇 egain or ◿ +.

Time, date, stop-watch



○ Press ◴ on the remote control.
▷ The time and the date appears.
If you need to set the current date and time refer to "CLOCK", page 11.
○ Press ◴ again to select the stop-watch. Press ◴ another time to start the stop-watch. If you now press ◴ again the time on the screen is stopped but the stop-watch is still running. Press ◴ to run the time on the screen again.
○ Press ◴ more than 5 seconds to switch off the stopwatch.

Sleep-timer

With this feature you can select a time period after which the TV switches automatically to Stand-by mode.



○ Press ⏻ until the required time period is displayed on the screen.
This time period can be set in steps of 15 minutes starting from 90 minutes downwards.
The count-down starts immediately after the time period is selected.
You can see the remaining time by pressing ⏻ once.
The time displayed on the screen will disappear within a few seconds.
During the final minute of the selected time period, the seconds remaining begin to "count-down" on the screen, informing you that the TV is going to switch off. At the end of this time period the TV switches to Stand-by mode.

○ If you want to stop the "sleep-timer" press ⏻ two or more times until the selected time period displayed is "00".

Personal Preference

○ If you press the green PP button on the remote control the brightness, contrast, colour and volume return to a fixed level. You can set this level to your personal preference using the MAIN MENU. (See "SPECIAL FEATURES" page 10).

Brightness and Colour control

○ Press ☼ — or + on the remote control to adjust the brightness.
○ Press ◍ — or + on the remote control to adjust the colour.
You can also control brightness and colour via the MAIN MENU. (See page 9).

Downloaded from www.Manualslib.com manuals search engine

MAIN MENU

In this chepter all the features relevant for daily use are explained: how to adjust the picture and the sound, how to use the alarm functions etc. You can edjust ell the settings by choosing items from the **MAIN MENU** on the screen.

GB

ADJUSTING THE PICTURE

You can set the brightness, colour and contrast according to your preference using the **PICTURE** menu.



1

○ Press **MENU** on the remote control.
▷ The **MAIN MENU** appears.

2

○ Select **PICTURE** from the **MAIN MENU.**
▷ The **PICTURE** menu appears.

3

○ Press one of the colour button to select the item you want to adjust.
○ Press — or + in order to adjust **BRIGHTNESS, COLOUR** or **CONTRAST.**
○ Press — or + to set the **AUTOCONTRAST** or **SOUND ONLY** to **ON** or **OFF.**

AUTOCONTRAST
If this feeture is ON the TV eutomaticelly adjusts itself to the light conditions in your room. The sensor indicated ABC (Automatic Brightness Control) on your TV is ectiveted.

SOUND ONLY
If this feature is ON the TV screen has no picture, you will hear only the sound.

HELP **You can alweys press the MENU button on your remote control to go beck to the MAIN MENU, or press OFF to leave the menu.**

Downloaded from www.Manualslib.com manuals search engine

SPECIAL FEATURES

Here some features are explained which are very handy to use occasionally.

1 The **MAIN MENU** should be on your screen, if not:
O Press **MENU** on the remote control.
▷ The **MAIN MENU** appears.

2 O Select **SPECIAL FEATURES** from the **MAIN MENU.**
▷ The **SPECIAL FEATURES** menu appears.

3 O Press one of the colour buttons to select the features you want to activate.
O Press — or + in order to activate or disactivate the function.

CHILD LOCK
If this feature is ON the TV can only be operated with the remote control. The TV buttons have no effect. Use this feature to prevent undesired use of the TV. When you press a TV button **child lock** appears on the screen.



DISPLAY PROGRAMME NUMBER
If this feature is **ON** the green programme number is always present in the upper right hand corner of the screen. If this feature is OFF the programme number is present a few seconds after changing a TV channel.

PERSONAL PREFERENCE
You can store your personal preferred picture and sound. These preferences can be recalled with the green **PP** (Personal Preference) button on the remote control. Follow these steps to set your personal preference.

1. Set the brightness, colour end volume, using the ☼ - ⚽ ◿ buttons on the remote control.
2. Select **PERSONAL PREF.**
3. Press — or + to store your settings.

Nota: With "Personal Preference" you define a preferred general volume level. However, some TV channels transmit different volume levels (e.g. MTV). So, when pressing the green PP button, the volume levels of certain TV channels may be too loud or too soft. Via the INSTALLATION menu the volume level per channel can be adapted. (See page 5).

DIGIT ENTRY TIME
To choose a programme number from 10 to 59 you must press two digits within a certain period. You can choose a LONG or a SHORT period.

HELP **You can always press tha MENU button on your remote control to go back to the MAIN MENU, or press OFF to leave the menu.**

Downloaded from www.Manualslib.com manuals search engine

CLOCK - setting time and date

When you press ⏲ on your remote control, the clock and the date will appear. After a few seconds it will automatically disappear.
Follow these steps to set the actual time and date.

1

The **MAIN MENU** should be on your screen, if not:
○ Press **MENU** on the remote control.
▷ The **MAIN MENU** appears.

GB

2

○ Select **CLOCK** from the **MAIN MENU**.

3

○ Select **TIME**.
○ Press the digit buttons to insert the time.
○ Select **DATE**.
○ Press the digit buttons to insert the date.
○ Select **STORE**.
▷ The clock starts running with the new time.
The time runs as long as the TV is switched on.

HELP

You can always press the MENU button on your remote control to go back to the MAIN MENU, or press OFF to leave the menu.

ALARM

When the **ALARM** is **ON** the TV automatically switches to a set TV channel at a set time. You must specify the programme number and the time. Follow these steps:

1

○ Check if the clock is set to the right time using the ⏲ button on the remote control. To adjust the time see "CLOCK" on this page.

2

The **MAIN MENU** should be on your screen, if not:
○ Press **MENU** on the remote control.
▷ The **MAIN MENU** appears.

3

○ Select **ALARM**.

4

○ Select **SWITCH-ON TIME**.
○ Press the digit buttons to insert the starting time for the TV programme.
○ Select **PROGRAM NUMBER**.
○ Press the digit buttons to select the programme number.
○ Press — or + to select **ON/OFF**. Select **ON** to activate the alarm. Select **OFF** to desactivate the alarm.

You will see a yellow light on the front of the TV, if the **ALARM** is switched **ON**.

HELP

You can always press the MENU button on your remote control to go back to the MAIN MENU, or press OFF to leave the menu.

Downloaded from www.Manualslib.com manuals search engine

Teletext

Most TV channels broadcast information via teletext. Each channel which broadcasts teletext transmits a page with information on how to use its teletext system. Look for the teletext page with the index (usuelly page 100). TV programmes are sometimes subtitled for the hard of hearing. Depending on the TV channel, teletext is transmitted in different systems: WST, TOP, FLOF.

Switching Teletext On and Off

O Select the TV channel for the desired teletext broadcast. Teletext cannot be switched on when there is a menu on the screen.
O Press ▤ to switch on the teletext.
▷ The contents appear on the screen together with an information line at the top and an options line at the bottom.



In the information line appears:
- the number of the pege transmitted or requested.
- the page counter.
- the name of the TV channel.
- date and time.
- only Page100 if there is no teletext broadcast.

O Press ▤ again to switch off the teletext.
▷ The TV channel reappears.

Selecting a Teletext Page

With direct page selection
O Enter the desired pege number with the digit buttons.
▷ The page counter seeks the page.
▷ If the counter keeps searching, then the page is not available.

or

With the options line
O Select the desired subject with the corresponding colour button.
▷ The selected subject consists of a page and new options line.
O With the red button or the blue button select either the previous or the following page, indicated in the options line with a red — a blue +.

Does P ?... appear or have you entered en incorrect number? First complete the number with random figures and then enter the correct page number egain.

Selecting the table of contents
O Press the white colour button or ⓘ.
▷ The table of contents will appear.

HELP **You can always press ▤ to switch off teletext.**

Downloaded from www.Manualslib.com manuals search engine

Special teletext functions

Hold
A selected page number sometimes contains automatically rotated subpages. The total number of subpages and the subpage displayed are indicated on the screen. For example: 1/4.
○ Press ⇳ to hold a subpage.
▷ ⇳ appears in the information line.
The information in this subpage is not being updated by the teletext editoriel office.
○ Press ⇳ again.
▷ The subpages rotate again.

Reveal
Some pages contain concealed information, such as solutions to riddles and puzzles.
○ Press ? to call up concealed information.
○ Press ? again to switch off the concealed information.

Interrupt
○ Press X.
▷ The TV chennel appeers.
▤ indicates thet you ere still in the teletext mode. Before interrupting teletext, you can select a page number. When the page has been found, the information line appears briefly on your screen.
○ Press X again.
▷ Teletext reappears.

Mix
○ Press ◪.
▷ The teletext page is superimposed over the programme on the screen.
○ Press ◪ again.
▷ Only the teletext page is displayed.

Enlarge
○ Press ⇕ to enlarge the top half of the teletext page.
○ Press ⇕ again to enlarge the bottom half of the teletext page.
○ Press once more to return to normal page size.

Subcode
By edding e subcode you cen cell up e subpage end hold it.
○ Enter the pege number.
○ Press ◕.
○ Enter the subpage with 4 digits: e.g. 0003 for 3/7.
○ Press X.
▷ The TV channel appears. The information line appears as soon as the subpage has been found.
○ Press X again.
○ Press ◕ to cancel the subcode.

Exit
○ Press ▤.
▷ The TV programme appeers on the screen egain.

Time
The time can only be called up if the TV channel you are watching is also broadcasting teletext.
○ Press ◕.
▷ The time eppears.
○ Press ◕ agein to switch off the time or wait a few seconds.

Downloaded from www.Manualslib.com manuals search engine

Peripheral connections

Your TV has many possible connections. This drawing shows the most common connections. Pleese esk your deeler to connect equipment not mentioned here or for stacking and looping equipment.



Using the TV remote control for the videorecorder

Videorecorders accepting the RC5 code can be operated with the remote control supplied.
If you went to use the TV remote control to operate the videorecorder, slide the button on the side to **VCR** position.

Downloaded from www.Manualslib.com manuals search engine

Connections

Aerial connections



GB

You can connect your videorecorder or other equipment via the aerial connection
on the back of tha TV.
You must seerch for the signal from the peripheral connected.

- O Unplug the aerial plug from your TV and insert it into the aerial input of your equipment.
- O Connect another aerial plug to the output TV of your equipment, connect the other side to the aerial input of your TV.
- O Switch on your equipment.
- O Check in the handbook of the particular equipment to see what the test signal looks like.
- O Now use the **MANUAL STORE** menu to search for end store this signal on a programme number. From now you can receive signals from your equipment on this programme numbar.

Euroconnection (scart)

You can connect your videorecorder, camcorder, CDV player, cd, satellite tuner, game computer, CD-Interective or other equipment via the euroconnector socket on the back of the TV. Ask your dealer for the appropriate cable.

Normally if the peripheral is switched on, the picture will automatically appear on the TV screen; if not press on your remote control.

- O Press to switch to TV.

Audio/video connections

You can connect your audio or video equipment to the TV AUDIO/VIDEO connectors on the back of the TV. Ask your dealer for the appropriate cable.



- O Connect the audio cables to the audio input of your equipment and to **(OUT)** of your TV.
- ▷ If audio aquipment is connected you can listen to your TV sound via your audio equipment.
- O Press on the remote control.
- ▷ The internal loudspeakers of your TV are switched off.
- O The video equipment must be connected to the **IN CVBS** and to the **AUDIO IN** of your TV.

Normally if the peripheral is switched on, the picture will automatically appeer on the TV screen; if not press on your remote control.

- O Press to switch to TV. .

Headphones



- O Insert the plug into the headphones socket at the front of the TV. Adjust the volume with — or +.
- ▷ The internal loudspeakers of your TV are automatically switched off.
  You can connect headphones with an impedence between 8 and 4000 Ohm, the jack type is 3,5 mm.

If you want to connect more electronic equipment to your TV, consult your deeler.

Downloaded from www.Manualslib.com manuals search engine

Tips

Poor or no picture:

Is your TV set or indoor aerial located too close to loudspeakers, unearthed audio equipment or neon lights, etc.?
Is the eeriel connected properly?
Are the plugs tightly connected to the aerial socket and are the connection facilities to any other installed TV in good condition?
If en indoor aerial is used, refer to the "Unpack and Connect" section to improve the reception.
No sound? Have you selected the right TV system?

Remote control is not working properly:

Probably the batteries are flat, replece the batteries.
Is the **TV/VCR** slide switch in the **TV** position?
Do you hear something from your remote control?
Its normal. You hear the gravity switch which makes sure you can work with both sides of the remote control.

The TV is not responding to the buttons on the TV?

Check if the child lock is OFF.

No picture from connected equipment:

Is your TV switched to ext. equipment ?
O Press ⊡→ one or more times.
Is the electronic equipment switched on and is START or PLAY pressed?
No picture from your videorecorder, or other equipment connected via Euroconnector (scart)?
O Press ⊡→ to switch to EXT.1.

Demo

Do you see the word DEMO on your screen? Then your TV automatically shows you the main functions in the menu. Press the buttons PROGRAM — and VOLUME + on your TV et the same time. DEMO is then switched off (or ON).

No solution

Switch your TV off and on again with the ⏻ button.

Never attempt to repair a defective TV set yourself.

Switch off the TV and call your dealer or TV-technician when nothing helps or when:
- A white horizontal stripe appears ecross the whole screen.
- The yellow lamp below the screen starts blinking when no buttons are pressed on the remote control.

Downloaded from www.Manualslib.com manuals search engine

Pick location	am	Invoicenumber	Wave	Sort location
4B6-K04-K3	1401	5559393-0004	03	09-015

Cust.code	Quantity
	1

	Stock	Invoice and ship to	Order	Date
1958	10	381403 170866	180997	384

Qty. SPQ	Service code	Description	SPQ
1	4822 736 53009	MODE D'EMPLOI	1

4822 736 53009
A1

Made in: 64

Downloaded from www.Manualslib.com manuals search engine

(GB)	**IDENTITY CARD**	This card, together with the terms of guarantee (to be provided by your dealer), forms the full certificate of guarantee for this appliance.
(D)	**DERÄTE-KENNKARTE**	Diese Karte ist, zusammen mit den Garantiebestimmungen, d.e Ihr Handler Ihnen aushandigt, Ihr Garantieschein für dieses Gerät
(F)	**CARTE D'INDENTIFI-CATIDN**	Associée aux conditions de garantie (qui vous sont remises par le revendeur), cette carte constitue le certificat de garantie de cet appareil.
(NL)	**INDENTIFI-CATIEKAART**	Deze kaart vormt, samen met de garantievoorwaarden (welke door uw dea'er verstrekt worden), het garantiebewijs voor dit apparaat.
(I)	**CARTA D'IDENTIFI-CAZIONE**	Questa cartolina rappresenta insieme alle condizioni di garanzia (da consegnare dal vostro rivenditore) il documento di garanzia per questo apparecchio.
(E)	**TARJETA DE INDENTIFICACIÒN**	La garantía de este aparato se compone de esta tarjeta y de las condiciones de garantía que le entregará su concesionario.
(P)	**CARTÃD DE INDENTIFICAÇÃO**	Este cartão, em conjunto com as condições de garantia em vigor (explicadas pelo seu vendedor) constituem o certificado de garantia do seu aparelho
(GK)	**I.D. KORT**	Dette kort, udfyldt af Deres forhandler, er tilstrækkelig garantidokumentation for dette apparat.
(N)	**IDENTIFIKA-SJOSKORT**	Dette kort, sammen med garantibetingelsene (som De får av forhandleren) utgjør garantibeviset for dette apparat
(S)	**IDENTIFIERINDS-KORT**	I Sverige gäller särskilda konsumentbestammelser Var vanlig kontakta radiohandlaren for information
(SF)	**TUNNISTUS-KORTTI**	Taman laatteen takuutodistus muodostuu testa kortiste ja takuuehdoista (jalleenmyyja antaa mukaan)
(GR)	**ΔΕΛΤΙΟ ΤΑΥΤΟΤΗΤΑΣ**	Η καρτέλλα αυτη μαζι με τους ορους εγγυήσεως (που θα προμηθευθειτε από το καταστημα που αγορασατε την συσκευή) αποτελουν το πλήρες πιστοποιητικό εγγυήσεως της συσκευής σας

PHILIPS

RC 3119 105 2027.1

Printed in Italy by G.S.F 92/12 11 10 9 8 7 6

15AB3536
17AB3546
21AB3556

RC 3119 105 2027.1

Downloaded from www.Manualslib.com manuals search engine